



## **INGENIUS Entrance Matting Installation**

Ingenius should ideally be fully adhered for best results when used as a wall to wall foyer carpeting. Single sections may be loose-laid in a matwell recess, but multiple sections should be fully bonded.

The subfloor must be smooth, dry, level and free from any contaminants. Any irregularities should be levelled using a standard flooring self-levelling screed.

Recommended adhesives are:

“Jaybond” Acrylic Adhesive for indoor dry areas.

Or

“PU2000” Polyurethane Adhesive for external/wet areas

A carpet edging trim may be required to complete the installation if there is a variation in thickness between the Ingenius and the surrounding floor covering.